

PRODUCT INFORMATION ACCESSORY
LT-Z 400K6-K7






Bensheim, October 2008






Way of Life!

QuadSport **Z400**



<p>Front bumper, K6-K7 P/N 990D0-07G00-045</p> <p>Installation time: 0,2h</p>	
<p>Shock cover set, blue, K6-K7 P/N 990D0-07G00-SAC</p> <p>Installation time: 0,2h</p>	
<p>Nerf bar set, K6-K7 P/N 990D0-07G00-030</p> <p>Installation time: 0,5h</p> <p><i>Replacement parts</i> Footpegs, aluminium P/N 990D0-07G00-036 Nylon stripes for nerf bar P/N 990D0-07G00-033</p>	
<p>Extended footrest set, K6-K7 P/N 990D0-07G00-038</p> <p>Installation time: 0,2h</p>	
<p>Arm guard protection set, K6-K7 P/N 990D0-07G00-040</p> <p>Installation time: 0,25h</p>	

<p>Lever protection, aluminium, K6-K7 P/N 990D0-07G00-057</p> <p>Installation time: 0,1h</p>	
<p>Engine guard, K6-K7 P/N 990D0-07G00-048</p> <p>Installation time: 0,4h</p>	
<p>Swing arm cover, aluminium, K6-K7 P/N 990D0-07G00-055</p> <p>Installation time: 0,4h</p>	
<p>Rear carrier, K6-K7 P/N 990D0-07G00-060</p> <p>Steel, black painted</p> <p>Installation time: 0,1h</p>	
<p>Soft-bag, 30litres P/N 990D0-07G00-BAG</p> <p>Dim.: H: 23cm, W: 52cm, D: 23cm</p> <p>Fits to rear rack – P/N 990D0-07G00-060</p> <p>Including rain hood. Left side case is removable.</p> <p>Installation time: 0,1h</p>	

<p>Backpack, 29litres P/N 990D0-04129-000</p>	
<p>Optimate 3 battery charger P/N 997SO-14F00-BAT</p> <p>Suited for 12V-batteries for charging, with diagnostics function. This equipment has a charge current of max.0.6 amp.</p>	
<p>First-aid-set P/N 999LP-FIRST-AID</p> <p>A must on every tour.</p> <p>Compulsory when travelling to Austria!</p>	
<p>Tires-repair-set P/N 997SO-TIRES-REP</p> <p>First aid for puncture on the way. For tubeless tyres.</p>	